



**CROSSFIRE Series**

**SAFE-TAK BASE-2.5" M INLETS**

**XFH-2NJ**

DOUBLE INLET-1250 GPM VERSION

**\$2867.00 List Price**

**FEATURES**

is supplied with either two clappered swivel inlets or with a single full-time swivel inlet. The stainless steel, carbide-tipped base support legs can be folded to easily fit inside a small apparatus compartment, or for carrying pre connected to a hose line. Includes a safety tie-down strap with attached storage cap.

## SPECIFICATIONS

<b>Coupling Size Side A</b>	2.5" (65 mm)
<b>Coupling Size Side B</b>	2.5" (65 mm)
<b>Coupling Style Side A</b>	Rocker
<b>Finish</b>	Fire Engine Red
<b>Horizontal Control</b>	N/A
<b>Horizontal Movementdegrees</b>	N/A
<b>Inlet</b>	Portable Base Dual Inlet
<b>Max Flow</b>	1,250 gpm (4,500 l/min)
<b>Operation Energy Source</b>	Manual
<b>Oscillation</b>	No
<b>Outlet</b>	Quick Connect Male
<b>Package</b>	No
<b>Safety Shutoff</b>	No
<b>Valve Design</b>	No Valve
<b>Vertical Control</b>	N/A
<b>Vertical Movementdegrees</b>	N/A
<b>Weight</b>	25
<b>Safety Inlet</b>	Yes

## DOCUMENTS

### Service Procedures

[CROSSFIRE XF500-KIT & XP500-KIT INSTALLATION INSTRUCTIONS \(PDF\)](#)

[PARTS LIST: CROSSFIRE & SAFE-TAK 1250 \(PDF\)](#)

[PARTS LIST: CROSSFIRE & SAFE-TAK 1250 \(PDF\)](#)

### Instructions For Installation, Safe Operation and Maintenance

[CROSSFIRE STORAGE BRACKET \(PDF\)](#)

[CROSSFIRE® MONITOR MANUAL \(PDF\)](#)

[MONITOR EXTENSION PIPE \(PDF\)](#)

[Z FRENCH MANUEL : CANON À EAU CROSSFIRE®](#)

[Z GERMAN CROSSFIRE® MONITOR MANUAL \(PDF\)](#)

[Z ITALIAN CROSSFIRE® MONITOR MANUAL \(PDF\)](#)

[Z POLISH CROSSFIRE® MONITOR MANUAL](#)

[Z SPANISH MONITOR CROSSFIRE \(PDF\)](#)

### Technical Specifications and Drawings

[MONITOR DRAWING AND PART LIST \(PDF\)](#)

[PARTS LIST: CROSSFIRE BRACKET \(PDF\)](#)

[XFH-2NJ FINISHED GOOD PRINT \(DXF\)](#)

[XFH-2NJ ITEM SPECIFICATION \(DOC\)](#)

[XFH-2NJ ITEM SPECIFICATION \(DOC\)](#)

[XFH-2NJ LEGS FOLDED FINISHED GOOD PRINT \(ZIP\)](#)

### Online Videos

[CROSSFIRE CUP SEAL REPLACEMENT \(MP4\)](#)

[CROSSFIRE SERIES VIDEO \(MP4\)](#)

[HOW TO UPGRADE A STANDARD BLITZFIRE TO AN OSCILLATING BLITZFIRE \(MP4\)](#)

### Technical Bulletins & Testing Reports

[CROSSFIRE® AND HURRICANE™ SHAFT SEAL CHANGE \(PDF\)](#)

[PRODUCT BULLETIN 3" AND 4" MONITOR FLANGE CONNECTION CHANGE \(PDF\)](#)

[PRODUCT BULLETIN MANUAL EXTEND-A-GUN WITH CROSSFIRE® INLET MOUNT \(PDF\)](#)

[PRODUCT BULLETIN PORTABLE MONITOR STORAGE BRACKET LABEL CHANGE \(PDF\)](#)

### Certifications & Approvals

[CROSSFIRE WITH STOW-A-WAY BASE EN15767-1 \(PDF\)](#)

## **ABOUT THE CROSSFIRE SERIES**

The CROSSFIRE monitor is a unique master stream appliance that's lightweight, compact and incredibly versatile. It can be connected to either a portable base or a truck.

With a flow rating of 1250 gpm in portable operation, the TFT Crossfire monitor integrates the exclusive Safe-Tak safety shutoff system to prevent unintentional movement. The monitor's compact and lightweight design includes stainless spring steel legs with carbide tips for maximum stability, and a visual attachment indicator for additional security.

Connect to a truck with the adapters or a TFT Extend-A-Gun with XL outlet. The connection is easy, positive, and visually verified. When in use, the release is "locked out" by water pressure. The waterway is a large 3.25" (83mm) which lets the CROSSFIRE deliver up to 1250 gpm (4500 l/min) with low friction loss.