



CROSSFIRE Series

STOW-A-WAY BASE 2.5\"/>

XPL-2BJ

DOUBLE INLET 3500 LPM NO SAFETY VALVE

\$2090.00 List Price

FEATURES

WITHOUT SAFE-TAK VALVE is supplied with either two clappered swivel inlets or with a single full-time swivel inlet. Includes a safety tie-down strap with attached storage cap. STOW-A-WAY 800 portable base is not equipped with SAFE-TAK™ "Flow Safety Valve." Maximum recommended flow with Stow-A-Way Base in portable mode is 800 gpm (3500 l/min). Order XF500-KIT Option \$570.00 to add a flow safety valve. Weight of safety valve is 3.1 lb (1.4kg).

SPECIFICATIONS

Coupling Size Side A	2.5" (65 mm)
Coupling Size Side B	2.5" (65 mm)
Coupling Style Side A	Rocker
Finish	International Red
Horizontal Control	N/A
Horizontal Movementdegrees	N/A
Inlet	Portable Base Dual Inlet
Max Flow	800gpm (3,500 l/min)
Operation Energy Source	Manual
Oscillation	No
Outlet	Quick Connect Male
Package	No
Safety Shutoff	No
Valve Design	No Valve
Vertical Control	N/A
Vertical Movementdegrees	N/A
Weight	32.2
Safety Inlet	No

DOCUMENTS

Service Procedures

[CROSSFIRE XF500-KIT & XP500-KIT INSTALLATION INSTRUCTIONS \(PDF\)](#)
[PARTS LIST: CROSSFIRE & SAFE-TAK 1250 \(PDF\)](#)
[PARTS LIST: CROSSFIRE & SAFE-TAK 1250 \(PDF\)](#)

Instructions For Installation, Safe Operation and Maintenance

[CROSSFIRE STORAGE BRACKET \(PDF\)](#)
[CROSSFIRE® MONITOR MANUAL \(PDF\)](#)
[MONITOR EXTENSION PIPE \(PDF\)](#)
[Z FRENCH MANUEL : CANON À EAU CROSSFIRE®](#)
[Z GERMAN CROSSFIRE® MONITOR MANUAL \(PDF\)](#)
[Z ITALIAN CROSSFIRE® MONITOR MANUAL \(PDF\)](#)
[Z POLISH CROSSFIRE® MONITOR MANUAL](#)
[Z SPANISH MONITOR CROSSFIRE \(PDF\)](#)

Product Order Forms

[CROSSFIRE COMBINATION PACKAGES ORDER FORM \(PDF\)](#)

Online Videos

[CROSSFIRE CUP SEAL REPLACEMENT \(MP4\)](#)
[CROSSFIRE SERIES VIDEO \(MP4\)](#)
[HOW TO UPGRADE A STANDARD BLITZFIRE TO AN OSCILLATING BLITZFIRE \(MP4\)](#)

Technical Specifications and Drawings

[MONITOR DRAWING AND PART LIST \(PDF\)](#)
[PARTS LIST: CROSSFIRE BRACKET \(PDF\)](#)

Technical Bulletins & Testing Reports

[CROSSFIRE® AND HURRICANE™ SHAFT SEAL CHANGE \(PDF\)](#)
[PRODUCT BULLETIN 3" AND 4" MONITOR FLANGE CONNECTION CHANGE \(PDF\)](#)
[PRODUCT BULLETIN PORTABLE MONITOR STORAGE BRACKET LABEL CHANGE \(PDF\)](#)

Certifications & Approvals

[CROSSFIRE WITH STOW-A-WAY BASE EN15767-1 \(PDF\)](#)

ABOUT THE CROSSFIRE SERIES

The CROSSFIRE monitor is a unique master stream appliance that's lightweight, compact and incredibly versatile. It can be connected to either a portable base or a truck.

With a flow rating of 1250 gpm in portable operation, the TFT Crossfire monitor integrates the exclusive Safe-Tak safety shutoff system to prevent unintentional movement. The monitor's compact and lightweight design includes stainless spring steel legs with carbide tips for maximum stability, and a visual attachment indicator for additional security.

Connect to a truck with the adapters or a TFT Extend-A-Gun with XL outlet. The connection is easy, positive, and visually verified. When in use, the release is "locked out" by water pressure. The waterway is a large 3.25" (83mm) which lets the CROSSFIRE deliver up to 1250 gpm (4500 l/min) with low friction loss.