


Extenda-Lite Pull-up and Push-up Pole Order Guide





STEP 1: SELECT YOUR LIGHT HEAD

Select the appropriate light head for your available power supply (AC or DC).

AC (generator or shore-powered)

Description	Select One	Light Head	Lumens	Voltage	Wattage	Certifications	Head Height
SceneStar 	<input type="checkbox"/>	ELSS-XLAC	20,000	120	220	UL, ROHS, CSA	12"
	<input type="checkbox"/>	ELSS-XLAC2	20,000	240	220	CE, ROHS	12"

DC (truck battery-powered)

Description	Select One	Light Head	Lumens	Voltage	Wattage	Certifications	Head Height
SceneStar 	<input type="checkbox"/>	ELSS-SLDC	14,000	10-32	150	CE, ROHS	12"
	<input type="checkbox"/>	ELSS-XLDC	19,000	10-32	220	ROHS	12"
Revel (ELRE-XLDC shown below) 	<input type="checkbox"/>	ELRE-SLDC	14,000	10-32	110	ROHS	10.75"
	<input type="checkbox"/>	ELRE-XLDC	28,000	10-32	220	ROHS	10.75"

All SceneStar light head body colors are white and include black handles on the top and bottom of the light head.

Extra fees apply for items indicated with an asterisk (*).
Send PO & completed order guide to akroncare@idexcorp.com or call 800.228.1161

Extenda-Lite Pull-up and Push-up Pole Order Guide



STEP 2: SPECIFY PUSH-UP OR PULL-UP POLE LENGTHS

Pull-Up Pole* (PU) (extended from above)

Light head height

Inner Pole
48" or custom

Dim C

Outer Pole
58" or custom

Dim B

Length Below Top Mount =
Bottom of the top mount to the bottom of the pole (Dim C - 4")

Dim A

Stowed Position Max Height =
Light head + Outer Pole

Extended Position Max Height =
(Inner pole + Outer pole + Head height) - 2"

Select the pole options and lengths.

Pole Options

Push-Up Pole (PS)*
(extend from below with a grip)

Pull-Up Pole (PU)*
(extend from above)

Pull-Up Pole Lengths

Standard Pole Length
48" Inner Pole, 58" Outer Pole

Custom Pole Length

Inner Pole Length: _____

Outer Pole Length: _____

Push-Up Pole Lengths

Standard Pole Length
60" Inner Pole, 11.5" Outer Pole

Custom Pole Length

Inner Pole Length: _____

Outer Pole Length: _____

Push-Up Pole* (PS) (extended from below)

Light head height

Dim C

Outer Pole
11.5" or custom

Dim B

Inner Pole
60" or custom

Dim A



Max Height =
Light head + Inner Pole

Extra fees apply for items indicated with an asterisk (*).
Send PO & completed order guide to akroncare@idexcorp.com or call 800.228.1161

Extenda-Lite Pull-up and Push-up Pole Order Guide




STEP 3: SELECT ACCESSORIES

Collars	
<input type="checkbox"/> Twist Lock (standard)	
<input type="checkbox"/> Lock Collar with knob (LC)	

Mounting Brackets (pick all that apply)	
<input type="checkbox"/> No Brackets	
<input type="checkbox"/> Side mount brackets 2 1/8" offset, Qty. 2 (SM2)*	
<input type="checkbox"/> Side mount brackets 4 1/4" offset, Qty. 2 (SM4)*	
<input type="checkbox"/> Top mount bracket (TM)* <i>pull-up only</i>	

Wire Out Location
<input type="checkbox"/> Bottom of the pole (shown)
<input type="checkbox"/> At the top of the pole & below the light head (WO)*

Up Indicator Switch	
<input type="checkbox"/> Yes (UI)*	
<input type="checkbox"/> No	

Plug Options	
<input type="checkbox"/> No Plug	NA
<input type="checkbox"/> L6-20 Twist lock	AC 240 V only
<input type="checkbox"/> L5-15 Twist lock	AC
<input type="checkbox"/> 5-15 (15 amp)	120 V only
<input type="checkbox"/> 5-20 (20 amp) plug*	120 V only

Your configuration is complete for Push-up or Pull-up pole-mounted Scenestars. Send your PO and this guide to akroncare@idexcorp.com. Questions? Call 800.228.1161.

Push-Up Pole Shown with wire out the bottom.

Extra fees apply for items indicated with an asterisk (*).
Send PO & completed order guide to akroncare@idexcorp.com or call 800.228.1161