

Datasheet

Talentum® Flame Detector IR2 Ex d [EN] 16511-00

The Talentum® Flame Detector IR2 Ex d is designed to protect hazardous areas where open fires may be expected and detects almost all flames, including hydrocarbon fires with 4.3 µm emissions through to invisible fires such as hydrogen.

The IR2 Flame Detector is sensitive to flickering, low frequency (1-15 Hz) infra-red radiation emitted by flames during combustion even if the lens is contaminated by a layer of oil, dust, water, vapour or ice.

This detector has two IR sensors which respond to different IR wavelengths in order to discriminate between flames and spurious sources of radiation. False alarms from flickering sunlight are avoided by a combination of filters and signal processing techniques.

The Talentum® IR2 detector has selectable output options of relay contacts or 4-20 mA signal, as standard.

FE	ATURES	

- High immunity to false sourcesTolerant of fumes, vapours, dust and mistSuitable for indoor areasDetects flames through glassUnaffected by convection currents, draughts or windProven response to multiple fuel typesMulti-spectrum detectionSelectable output options
- Selectable response speed
- Selectable sensitivity levels
- Built in auto and manual test
- Low current consumption
- Fast response to fire

APPROVALS

Worldwide approvals include EN54:10, LPCB, ATEX, and IECEx certification. Visit **ffeuk.com** for up-to-date approvals information.



Nuclear power sites Pharmaceutical production	
•	
Printing	
Spray booths	
Waste recycling	
Ś	

ACCESSORIES	
07127-00	Adjustable Mounting Bracket
07279-00	Weather Shield (Ex d) [SS]
12555-00	Air Purge (Ex d)
1800-101	Talentum Test Torch



Talentum® Flame Detector IR2 Ex d 16511-00

MECHANICAL SPECIFICATIONHousing materialCopper free aluminium alloyHousing colourRedDimensions158(h) x 149(w) x 134(d) mm
(6"(h) x 57/8"(w) x 51/8"(d))Weight2.3 kg (5 lbs)Cable gland entries3 x 20 mm (3 x ¾")Wiring1.0 to 4.0 mm² (12 - 18 AWG)

ELECTRICAL SPECIFICATION				
Supply voltage	14 to 30 VDC			
Quiescent current	8 mA, RL2 energised 4 mA, current loop, RL2 off 3 mA, RL2 off			
Alarm current	28 mA, RL1 & RL2 energised 20 mA, current loop, RL1 & 2 off 9 mA, RL1 energised			
Power-up time	2 seconds max.			
Self test voltage	14 to 30 VDC			
Relay outputs	Programmable operation including latching or non-latching			
Relay maximum ratings				
Current	0.75 A			
Voltage	48 Vdc			
Power	30 W			
(Note: resistive loads only)				

Refer to User Manual for further details

ENVIRONMENTAL

Operating temperature	-10°C to +55°C (+14°F to +131°F)		
Storage temperature	-20°C to +65°C (-4°F to +149°F)		
Relative humidity	95% non condensing		
IP rating	IP66		

PERFORMANCE			
Range			
High (Class 1)*	0.1 m² n-heptane at 25 m		
Low (Class 3)	0.1 m² n-heptane at 12 m		
	(see EN54:10 for sensitivity settings)		
Field of view	90° min. Cone		
Operating wavelength			
IR	1.0 to 2.7 µm		
* Has been tested and approved at Class I			




RESPONSE CHARACTERISTICS – HIGH SENSITIVITY					
Fuel	Flame size m² (in²)	Distance m (ft)	Approval		
n-Heptane*	0.1	25	EN54-10		
(Yellow flame)	(144)	(82)			
Methylated spirit*	0.25	25	EN54-10		
(Clear flame)	(400)	(82)			

Response time: typically 4 seconds


* Has been tested and approved at Class 1

FIELD OF VIEW



To meet the requirements of EN54-10:2002 clause 5.4 (Directional Dependence), viewing angles must not exceed $\pm 20^{\circ}$.

DIMENSIONS



INSTALLATION RECOMMENDATIONS

Please refer to our User Manual for mounting and wiring instructions. The installation of Talentum[®] flame detectors should be undertaken in accordance with recognised national or international standards and codes of practice.



FFE Limited, 9 Hunting Gate, Hitchin, Hertfordshire SG4 0TJ, UK t: +44 (0) 1462 444 740 e: sales@ffeuk.com w: ffeuk.com FFE Limited, 1455 Jamike Ave Ste 200, Erlanger, KY 41018-3147, USA t: +1859 957 1570 e: america@ffeus.com w: ffeus.com Specifications and wiring information are provided for information only and are believed to be accurate. FFE Ltd assumes no responsibility for their use. Data and design are subject to change without notice installation and wiring instructions are shipped with the products and should always be used for actual installation. For more information, contact your Sales Representative. Document Part No: 24-024-05